

CARE INSTRUCTIONS – MONTEO™ AND LUXORA™ PANELS

Monteo™ and Luxora™ panels have durable surfaces, but care should be taken when handling, machining and installing the product so as not to damage their surfaces.

To reduce the risk of scratches, never slide or rub panels or component pieces over each other during stacking and handling.

- Never use hard or abrasive cleaning products such as scrubbing brushes, scrapers, pot scourers, steel wool, abrasive tools, or bleaching agents, as these can lead to mechanical or chemical damage.
- Some cleaning chemicals and liquids used on components during fabrication can cause staining if left on the surface for too long. These should be wiped away immediately after being applied using a soft damp cloth.
- Ensure all chemical residue is removed and repeat the process as necessary.
- Any spilt chemicals and liquids that can cause stains must be wiped away immediately using a damp cloth and soapy solution. Repeat this process as necessary.
- Always keep the protective film in place until installation is complete and all other service providers have finished their projects.
- The protective film on Luxora™ must be removed within one month of completion of the job to avoid it ageing and becoming difficult to remove.

DAILY CLEANING

- Always use a damp, soft, lint-free cloth for daily cleaning.
- For best results, use a mild soap and water solution with the soft cloth to remove daily grime. The cloth must be well wrung out to avoid overly wetting the surface.
- Always take care to prevent prolonged exposure to excessive moisture, especially at exposed edges and profiles of the panels.
- Diluted name-brand window-cleaning products (1 part window cleaner to 2 parts water) are effective for removing drying marks and smears.
- Monteo™ and Luxora™ do not require furniture polish on their decorative surfaces.
- Avoid using abrasive, highly acidic, or highly alkaline cleaning products.